



**NOTES:**

1. IF FLUME IS 7' OR WIDER, USE PIPE BOLLARDS  
7' x 6" DIA., AND FILL WITH CONCRETE  
PLACE AT BOTH START AND END OF FLUME  
BURY TO 4' DEPTH
2. SIDE SLOPES TO BE HYDROMULCHED.



**CITY OF  
DECATUR**

**DRAINAGE SYSTEM CONSTRUCTION DETAILS  
STORM SEWER CURBED FLUME  
AND PILOT CHANNELS**

REVISED MAR 2000  
SCALE: 1/2" = 1'  
SHEET: **D-10**